

## 2019 KTM 690 Enduro Brake Lever Install ADDENDUM

The new 2019 KTM 690 is equipped with a quick shifter as you likely know being a new owner. The quick shifter requires a sensor that detects shift shaft motion and this sensor is located on the side of the motor directly behind the brake lever.

Not the sensor itself, but the factory plastic cover causes interference with the Vanasche Motorsports aftermarket billet brake pedal. We have remedied this issue by supplying a new precision machined sensor cover to protect the sensor and re-route the existing wiring.

Please refer to the original install document for all steps necessary to remove/install the brake pedal. This document goes over sensor cover install only.

1. After removing brake pedal, remove the plastic sensor cover. Cut the zip tie that is holding the wire to the side of the sensor



2. Install new cover ensuring that the wire stays within the machined pocket of the new sensor cover. The wire should be exiting the cover towards the top and to the right of the upper cover mount screw.

BEFORE REINSTALLING THE BRAKE LEVER AND CASTING BE SURE THAT THE WIRE IS RESTING ABOVE THE MOTOR CASE SCREW AS SHOWN BELOW. If this is not accomplished the brake lever may rub/wear on the wire.

If needed extra wire slack can be had by pulling a small amount at each zip tie location working your way down the frame from rear shock area.



